






Air Vibrators

- Three types of Air Cushion Type: Low noise and highly durable. Piston does not directly hit plate.
 - Impact Type: Powerful and quiet featuring cushion sheet on plate for noise reduction.
 - Rotary Type: Low noise and steady vibration.









Selecting ON/OFF Valve

For intermittent operation, use the 3-port, 2-position valve that releases pressure in the vibrator when stopped. Vibrators do not work properly with 2-port valve. Please place valve as close to vibrator as possible.

Please see a example flow diagram for intermittent operation on page 48.

| Valve sizes and estimated vibrator quantity with 1 valve. | | | | | | |
|---|-----|-----|-----|-----|-----|---|
| Model | 1/8 | 1/4 | 3/8 | 1/2 | 3/4 | 1 |
| NLV-1518A | 2 | 3 | 5 | | | |
| NLV-2125A | 1 | 2 | 4 | | | |
| NLV-2430B | 1 | 2 | 3 | | | |
| NLV-4856A | | | 1 | 2 | 5 | |
| NLV-55 | | | 1 | 2 | 4 | |
| NLV-75A | | | | 1 | 3 | 5 |
| NLV-1518AL | 1 | 2 | 4 | | | |
| NLV-2125AL | 1 | 1 | 3 | 5 | | |
| NLV-2430BL | 1 | 1 | 3 | 5 | | |
| NLV-4856AL | | | 1 | 2 | 3 | |
| NRV-30112 | 2 | 3 | 5 | | | |
| NRV-5223 | | | 1 | 2 | 5 | |